



SUFFOLK CENTRE

TIPS AND IDEAS



(Researched and written by Chris Sanderson)

Hitch-up Cabling 12N & 12S plugs.



Using a length of plastic cable tidy spiral, wrap this around each cable from the point where it leaves the A frame to its plug securing each end with electrical tape. Spiral wrap cable tidy can be purchased from a number of outlets such as Maplin etc and you will need to select a size that will grip the caravan cables tightly once wrapped around. i.e. a core size smaller than your cables diameter. In calculating the length required - add a third to your cables length as a minimum. Not only will the cable wrap protect you cables but it will allow "pig tails" to be made and maintained in shape keeping cables up out of harms way and not hanging down. Don't forget the same idea can be applied to the newer 13pin cabling.