



SUFFOLK CENTRE

TIPS AND IDEAS



(Researched and written by Chris Sanderson)



Power ventilators – if your van is equipped with one (or more) of the fan type roof vents and you wish to give it a spring clean inside then access is very straightforward. Simply remove the four screws that secure the cover behind which the fan is located. Don't confuse the required screws with those that secure the outer rim piece of the ventilator. The cover can be removed and the fan will remain in place. Once the cover is removed it will give you access to clean the fan blades themselves.